



BRINGING MATERIALS INTO THE CELLULAR SCREENING CENTER

1. Leave all unnecessary items in the lockers or outside in the office.
2. Put on gloves and spray item liberally with sterile 70% ethanol (Fisher Sci. #04-355-54).
3. Wipe all surfaces thoroughly with cloth cleanroom wiper (Fisher Sci. #191305936).